

# Fitting Instructions Manual

E-Flex Easy Flexitank

A003



# **EFFICIENT**

# | Flexitank article numbers (printed on the SAFE flexitank label) to be fire. flexitank label) to be fitted according to this manual

- A003
- A0L3
- **AV03**
- AVL3
- AVP3
- AOP3




#### | Container Selection

Ensure the below for the containers...

- No older than 5 years.
   IMPORTANT: The above is the requirement of Container Owners Assossiciation. If it is not applicable ensure that below conditions are obtained.
- Manufactured according to ISO 668 norm.
- Weight tested to a minimum of 28,000kg.
- <u>Clean</u>, structurally sound and in excellent condition.
- No repairs on side walls and there is no damage to the floor.
- Use food grade containers only, that are free of any odor.
- There are no insects, soil or contaminants that may cause customs issues at the destination.










#### | Container Selection

DO NOT use damaged/broken containers like below.

Broken containers can be rejected by the shipping lines.



**Bulged Container** 



**Damaged Container** 



#### **Container Selection**

- Use ONLY standard containers designed according to ISO 668 international norm.
- Ensure that containers have lashing rings on the floor.








#### | Container Selection


Central lug position may differ from one container to another.

Ensure that there are lugs positioned at least 250cm from the doors.



#### | Container Selection

- Sweep the container carefully with a broom.
- Ensure that the door bolts are silicon covered.





- Ensure that nails, sharp and rough objects that may damage/puncture the flexitank are removed.
- Cover uneven areas on the walls and on the floor with duck tape (thick tape).









## **Container Lining**

If the condition of the container is good and free of splinters, lining is not necessary; however, if you prefer to line the container, use a corrugated paper or if purchased, use the pp fabric provided by LiquA as shown below.







#### Contents of the Box





Open the E-Flex box and ensure that the following are in the package:

- 1. E-Flex
- 2. Warning labels
- 3. Adhesive tapes
- 4. Cable ties

The box will be used as door protection board.

DO NOT throw it away!



# **Positioning the E-Flex**



- Position the E-Flex leaning to right to the wall on the right hand side.
- Unroll the E-Flex towards the front wall
- Unfold the E-Flex towards the left wall.
- DO NOT step on the E-Flex with hard shoes while unrolling.









# **Positioning the E-Flex**


 The distance between the E-Flex and the outer end of the container (NOT where the wooden floor begins) must be 20 cm. Use the label as a reference.



 Properly positioned E-Flex at the door side, covers the floor entirely and ends up at the front wall.

# **Positioning the E-Flex**

- DO NOT remove the pre-folding tapes.
- DO NOT open the folds.









#### **E-Flex Flexible Harness**

 E-Flex must be fastened to the lashing rings/lugs on the container floor in order to stabilize the flexitank during the transportation.








Tie the lashing strap to the CENTER lug/lashing ring "taut but not tight".

Central lug position may differ from one container to another that you may not find the lug positioned at the very center of the container. Ensure that the harnessing belts are tied to a lug positioned at least 250cm from the doors.







#### **IMPORTANT:**

E-Flex is designed such that it will stand at least 15cm away from the doors after the filling. Loose or improper tying will inactivate the harnessing system and may cause the E-Flex to shift/move towards the doors.

Also too tight/short belt tying may cause capacity loss and a possible damages.







ENSURE THAT BELTS ARE TIED TAUT BUT NOT TOO TIGHT.





DO NOT remove the pre-folding tapes.





Ensure that straps are tied to the CENTER lug/lashing rings!





#### **Door Protection**

- The flexible harness prevents any flexitank movement. However to make sure that any sharp object/bolts on the door does not damage the flexitank, the carton box should be collapsed and used for protection.
- The box will be used as a door protector. Collapse the box as shown.



#### **Door Protection**

Suspend the boards to the door closing bars.











#### **Check List**

Fill in the provided Check List and stick it to the door on the right hand side.







# **Warning**


IMPROPER FITTING MAY CAUSE CAPACITY PROBLEMS, INNER LAYERS MAY GET STUCK AND STRETCH. THIS MAY CAUSE SEVERE LEAKINGS. ONLY TRAINED AND LICENSED OPERATORS ARE ALLOWED TO FIT OUR FLEXITANKS.

IF FITTING OPERATION HAS BEEN PERFORMED AT ANOTHER LOCATION, PLEASE ENSURE THAT THE E-FLEX HAS NOT MOVED DURING LOCAL TRANSPORTATION.



# Warning Labels

- Stick the warning labels on the side walls and the doors of the container.
- Clean the surface of the container prior to sticking the label for better adherence.



22



#### What happens if I don't tie the harnessing belts?

You may consider the harnessing belts of E-Flex like the seat belt of your car. If you don't buckle your seat belt and no accident happens during your travel, you arrive to the final destination safely. However in case of an accident, due to lack of seat belt, you may die or get severely injured.

Same principal is valid for E-Flex. If you don't tie the harnessing belts, nothing may happen until the final destination but in the event of an impact or accident, flexitank may shift towards the doors and cause a severe damage.

Also, when the container arrives to the final destination, flexitank may bulge out of the container at the time consignee opens the door. This might create hazard to the operators.

Ensure that harnessing belts are tied according to LiquA instructions.





#### Do I necessarily need to line every container with a protective material?

No...

We ask you to clean the container and inspect the sharp objects on the container surface very carefully. If you feel confident about the conditions of the container, you do not need to line the container.

However, wooden floor of the containers may always have the possibility to contain splinters on the surface. Splinters as such may cause damage on the surface of the flexitank. We recommend lining the containers with carton boards or with pp woven material provided by LiquA.

IMPORTANT: Lining the container DOES NOT guarantee to protect E-Flex against splinters or sharp objects. Take necessary precautions as if there was no lining materials.





#### How important is it to position the E-Flex on the container floor?

It is very important...

20ft containers have 32m³ free space in it and we use up to 27m³ of it. We ask you to position the flexitank 20cm from the outer edge of the container. If E-Flex is positioned wrongly towards the front wall, every 10cm will cause capacity loss of 1m³.

Also E-Flex stands on the floor as a two dimensional object. Layers get open during the filling. Any mistake at the positioning of the E-Flex may cause inner layers to get trapped which may cause a rapture and leak.

Please follow this instruction very carefully.





# If I shorten the belts, untie the knots or position the flexitank in a different location can I reduce the flexitank capacity?

No.

- DO NOT change position of E-Flex on the floor of the container.
- DO NOT until the knots on the flexitank.
- DO NOT tie the harnessing belts to a different location other than shown at this manual.
- DO NOT change the foldings.
- DO NOT remove the guiding paper tapes on the E-Flex.

In the contrary, changing any of the above not only do not change the capacity but also creates a hazard which may end up with a leak. E-Flex is designed to be assembled as easy as possible. Our production team has already folded, knotted, taped and prearranged everything for an easy fitting. Do not change any of the above. Just unroll the E-Flex, position correctly and tie the belts to the proper lashing rings/lugs.

Changing any of the above DOES NOT reduce the capacity. Fill E-Flex within the tolerances mentioned at the label and datasheet.



#### FAQ

If the container is not in good condition, shall I use metal bars to support the side

walls?

No, E-Flex is a self supporting flexitank and it does not exert pressure to the side walls.

Under no circumstances DO NOT use any metal bars.

It is not needed, it does not help, in the contrary, metal bars may create a hazard, damage the flexitank surface and cause a leak.

DO NOT use any material other than the ones you find in the E-Flex box.





# **Common Fitting Mistakes**



DO NOT change the foldings



The distance must be 20 cm between the flexitank and the outer end of the container



The belt tying must be 'taut but not tight'





#### THANK YOU

UguA Europe
Calle Jose Aguirre 40, Pius 31/Jennos España
CP: 46011
+34-91 1238506
UguA Fabrika
Ataboy Cd. No 28 Kat 1 Çekmekby 34794 İstanbul
Türkiye
+90 216-312-8660

www.liquatrans.com

I info@liquatrans.com