

**EFFICIENT  
SMART  
SAFE**



## ***K-Flex Instructions Manual***

***K-Flex Compact***

Rev02-220218

**LiquA**

# Pallet Selection



- CP1 pallet must be used. No other pallet type is compatible.
- Pallet size must be 100 x 120cm, CP1 pallets must be in good condition, free of nails and sharp objects.
- Cover the surface of the pallet with a carton board.
- Pallets must have 2000kg Safety Working Load.

**EFFICIENT  
SMART  
SAFE**

# | Elements of the K-Flex Compact



Open the K-Flex box and ensure that the following are in the package:

1. K-Flex
2. Separator

# Setup



- Erect the K-Flex on a pallet.
- Position the K-Flex to the center of the pallet.


**EFFICIENT  
SMART  
SAFE**

# Setup



- Fix the elastic bands to the pallet corners.

# I Setup



- Position the separator at the top of the K-Flex.
- Fix the elastic bands to the separator corners.
- Ensure that all corners of the K-Flex are in the right position to maintain a cube shape.

# I Setup

**EFFICIENT  
SMART  
SAFE**



- Pull out the filling flange of the inner liner as much as possible.

# Coupling



- Remove the cap.
- The flange on the liner is 2" and has BSP threads. Use an appropriate connector. The connector at the pictures is 2" male camlock.
- You will need a **2" female cam-lock** coupling. (DIN EN 14 420-7)



# I Coupling



- Couple the hose to the flange.
- Support the hose. Fill at the center of the K-Flex.
- Ready for filling.

# Filling

- Support the hose to ensure that the inner liner does not get any stress at any time.
- Start filling at low speed, 30-50lt per minute for the first 20seconds.
- Ideal filling time is 5 minutes per 1000lt.



# Filling

After loading;

- Decouple the hose.
- Remove the adaptor/connector.
- Remove the air.
- Fasten the cap.



# Filling



- Twist the liner and push down.
- Twist the outer spout and make a knot.
- Draw the string at both sides of the spout and make a knot.



# | Fastening




Fasten and integrate top separator, K-Flex and pallet to each other.

- Position the straps as close as possible to the sides of the K-Flex.
- K-Flex must be tightly fastened/entrapped in between the top separator and pallet.

**EFFICIENT  
SMART  
SAFE**

# | Fastening



- Fasten the K-Flex at all four sides.



**EFFICIENT  
SMART  
SAFE**

# IMPORTANT



- Ensure that K-Flex is filled up to its nominal capacity.

# Storage



- Protect K-Flex from direct sun exposure.
- Indoor storage is recommended for K-Flex, if not possible, cover the full K-Flex with tarpaulin.





# Handling

**EFFICIENT  
SMART  
SAFE**



**This version of K-Flex is stackable two high ONLY.**


# Truck/Container Selection

- Ensure that containers are in excellent condition.
- No repair on side walls and no damages on the floor.
- Foodgrade containers only – free of odors.
- Sweep the container carefully with a broom.
- Ensure that nails and other objects that may damage/puncture the K-Flex are removed.
- Cover potential uneven areas on the walls and on the floor with duct tape (thick tape).



# Truck/Container Loading

EFFICIENT  
SMART  
SAFE



- Bolts on the doors may damage the surface of K-Flex. Cover the sharp edges of the bolts with silicon and cover the doors with thick carton boards.

# Discharging



- Remove the cap.
- Unarm/Rotate the handle.
- Ready for discharge.

**EFFICIENT  
SMART  
SAFE**

*LiquA*

THANK YOU

LiquA Europe  
Calle Jose Aguirre 40, Piso 3 Valencia España  
CP: 46011  
+34 91 1238506  
LiquA Fabrika  
Atabey Cd. No 28 Kat 1 Çekmeköy 34794 İstanbul  
Türkiye  
+90 216 312 8660

[www.liquatrans.com](http://www.liquatrans.com)

| [info@liquatrans.com](mailto:info@liquatrans.com)